

Make & Model	Type	Years	Bulk Quick Plug#	Pkg. Quick Plug#	Install Time	Harness Location	
			New#	New#			
BUICK							
Enclave		08-17	51422	51423	5	BH1	
CADILLAC							
Escalade		14-17	51451	51452	5	BH3	
		03-06	51352	51353	5	BH3	
		2002	51342	51343	5	BH3	
Escalade ESV		14-16	51451	51452	5	BH3	
CHEVROLET							
Avalanche		03-06	51352	51353	5	BH3	
Silverado 1500	Custom	2002	51342	51343	5	BH3	
		16-18	51451	51452	5	BH1	
		High Country	14-18	51451	51452	5	BH1
		LS	15-18	51451	51452	5	BH1
		LT	14-18	51451	51452	5	BH1
		LTZ	14-18	51451	51452	5	BH1
		SSV	15-18	51451	51452	5	BH1
		WT	14-17	51451	51452	5	BH1
		New Body	07-13	Truck is not equipped with a brake control harness. Hardwire #51515 to blunt cut wires under dash.			
		Classic Body	2007	51352	51353	5	BH3
	Silverado 2500		03-06	51352	51353	5	BH3
		99-02	51342	51343	5	BH3	
		03-06	51352	51353	5	BH3	
Silverado 2500 HD	High Country	15-18	51451	51452	5	BH1	
		LT	14-18	51451	51452	5	BH1
		LTZ	14-18	51451	51452	5	BH1
		WT	14-18	51451	51452	5	BH1
		New Body	07-13	Truck is not equipped with a brake control harness. Hardwire #51515 to blunt cut wires under dash.			
	Classic Body	2007	51352	51353	5	BH3	
Silverado 3500		03-06	51352	51353	5	BH3	
		01-02	51342	51343	5	BH3	
		03-06	51352	51353	5	BH3	
Silverado 3500 HD	High Country	15-18	51451	51452	5	BH1	
		LT	14-18	51451	51452	5	BH1
		LTZ	14-18	51451	51452	5	BH1
		WT	14-18	51451	51452	5	BH1
		New Body	07-13	Truck is not equipped with a brake control harness. Hardwire #51515 to blunt cut wires under dash.			
	Classic Body	2007	51352	51353	5	BH3	
Suburban		15-17	51451	51452	5	BH3	
Suburban 1500		15-16	51451	51452	5	BH3	
		03-06	51352	51353	5	BH3	
		00-02	51342	51343	5	BH3	
Suburban 2500		03-06	51352	51353	5	BH3	
		00-02	51342	51343	5	BH3	
Suburban 3500 HD		2016	51451	51452	5	BH3	
Tahoe		15-17	51451	51452	5	BH3	
		03-06	51352	51353	5	BH3	
Traverse	New Body w/Amber Turn Signals	00-02	51342	51343	5	BH3	
	w/Factory Tow Package	09-17	51422	51423	5	BH3	
CHRYSLER							
Aspen	w/Factory Tow Package	07-09	51332	51333	5	BH1	
DODGE							
Dakota	w/Factory Tow Package	97-11	51332	51333	5	BH1	
Durango	w/Factory Tow Package	11-17	51446	51447	5	BH8	
		98-09	51332	51333	5	BH1	
Ram 1500		2010	51438	51439	5	BH8	
Ram 2500		2010	51438	51439	5	BH8	
Ram 3500		2010	51438	51439	5	BH8	
Ram Pickup	All Full Size Pickups	95-09	51332	51333	5	BH1	
FORD							
Bronco	Full Size	94-96	51322	51323	5	BH2	
		92-93	51312	51313	5	BH1	
E-150		09-14	51432	51433	5	BH5	
		92-08	51322	51323	5	BH1	
E-250		09-14	51432	51433	5	BH5	
		92-08	51322	51323	5	BH1	
E-350 Super Duty		09-14	51432	51433	5	BH5	
		92-08	51322	51323	5	BH1	
E-450 Super Duty		09-14	51432	51433	5	BH5	
		92-08	51322	51323	5	BH1	
Excursion		00-05	51322	51323	5	BH2	
Expedition		13-17	51432	51433	5	BH5	
		97-12	51322	51323	5	BH2	
Explorer	w/Factory Tow Package	02-16	51322	51323	5	BH2	
		09-17	51436	51437	5	BH7	
F-150		04-08	51322	51323	5	BH2	
	Heritage Edition	2004	51322	51323	5	BH2	
F-150 & F-250 Light Duty		94-03	51322	51323	5	BH2	
F-250 Super Duty	Without Factory Trailer Brakes	2017	51436	51437	5	BH5	
		08-16	51432	51433	5	BH5	
		05-07	51372	51373	5	BH4	
		99-04	51322	51323	5	BH2	
F-350 Super Duty	Without Factory Trailer Brakes	2017	51436	51437	5	BH5	
		08-16	51432	51433	5	BH5	
		05-07	51372	51373	5	BH4	
		99-04	51322	51323	5	BH2	
F-250 & F-350 Heavy Duty		1997	51322	51323	5	BH2	
F-150, F-250, F-350		94-96	51322	51323	5	BH2	
F-Series Full Size Truck		92-93	51312	51313	5	BH1	
F-450 & F-550 Super Duty		08-16	51432	51433	5	BH5	
		05-07	51372	51373	5	BH4	
Flex	w/Factory Tow Package	12-15	51436	51437	5	BH7	
Windstar	w/Factory Tow Package	09-11	51322	51323	5	BH2	
		95-03	51322	51323	5	BH2	

GMC						
Acadia	Denali	11-18	51422	51423	5	BH1
	SL	16-18	51422	51423	5	BH1
		10-13	51422	51423	5	BH1
	SLE	07-18	51422	51423	5	BH1
	SLT	07-18	51422	51423	5	BH1
	Acadia Limited	Base	2017	51422	51423	5
Sierra 1500	Base	14-18	51451	51452	5	BH1
	Denali	14-18	51451	51452	5	BH1
	SLE	14-18	51451	51452	5	BH1
	SLT	14-18	51451	51452	5	BH1
	New Body	07-13	Truck is not equipped with a brake control harness. Hardwire #51515 to blunt cut wires under dash.			
	Classic Body	2007	51352	51353	5	BH3
Sierra 2500		03-06	51352	51353	5	BH3
		99-02	51342	51343	5	BH3
		03-06	51352	51353	5	BH3
		99-02	51342	51343	5	BH3
Sierra 2500 HD	Base	15-18	51451	51452	5	BH1
	Denali	14-18	51451	51452	5	BH1
	SLE	14-18	51451	51452	5	BH1
	SLT	14-18	51451	51452	5	BH1
	WT	2014	51451	51452	5	BH1
	New Body	07-13	Truck is not equipped with a brake control harness. Hardwire #51515 to blunt cut wires under dash.			
Sierra 3500	Classic Body	2007	51352	51353	5	BH3
		03-06	51352	51353	5	BH3
		01-02	51342	51343	5	BH3
	Base	15-18	51352	51353	5	BH3
	Denali	14-18	51352	51353	5	BH3
	SLE	14-18	51352	51353	5	BH3
Sierra 3500 HD	SLT	14-18	51352	51353	5	BH3
	WT	2014	51352	51353	5	BH3
		01-02	51342	51343	5	BH3
		14-17	51451	51452	5	BH1
	New Body	07-13	Truck is not equipped with a brake control harness. Hardwire #51515 to blunt cut wires under dash.			
	Classic Body	2007	51352	51353	5	BH3
Yukon		15-17	51451	51452	5	BH3
Yukon XL		15-17	51451	51452	5	BH3
	New Body w/Amber Turn Signals	00-02	51342	51343	5	BH3
HONDA						
Pilot		06-16	51392	51393	5	BH1
Ridgeline		2017	51392	51393	5	BH1
		06-14	51392	51393	5	BH1
HUMMER						
H2		03-07	51352	51353	5	BH3
INFINITI						
QX56		04-13	51382	51383	5	BH1
QX60	Base	14-17	51382	51383	5	BH1
	Hybrid	2014	51382	51383	5	BH1
QX80		14-17	51382	51383	5	BH1
JEEP						
Cherokee		14-16	51459	51460	5	BH1
Grand Cherokee	75th Anniversary	2016	51446	51447	5	BH8
	Laredo	11-18	51446	51447	5	BH8
	Limited	11-18	51446	51447	5	BH8
	Overland	11-18	51446	51447	5	BH8
	Overland Summit	2012	51446	51447	5	BH8
	SRT	14-18	51446	51447	5	BH8
	SRT8	12-13	51446	51447	5	BH8
	Summit	14-18	51446	51447	5	BH8
	Trackhawk	2018	51446	51447	5	BH8
	Trailhawk	14-18	51446	51447	5	BH8
KIA						
Borrego		09-11	51442	51443	5	BH1
LAND ROVER						
LR3		05-09	51322	51323	5	BH2
LR4		10-15	51322	51323	5	BH2
Range Rover	Including Sport	05-15	51322	51323	5	BH2
Range Rover Evoque		12-16	51322	51323	5	BH2
LEXUS						
GX460		10-15	51362	51363	5	BH1
GX470		03-11	51362	51363	5	BH1
LX470		03-07	51362	51363	5	BH1
LX570		13-15	51362	51363	5	BH1
		08-11	51362	51363	5	BH1
LINCOLN						
Mark LT		06-08	51322	51323	5	BH2
MKT	w/Factory Tow Package	12-15	51436	51437	5	BH7
		10-11	51322	51323	5	BH2
Navigator		13-17	51432	51433	5	BH5
		98-12	51322	51323	5	BH2
MERCURY						
Mountaineer	w/Factory Tow Package	02-10	51322	51323	5	BH2

NISSAN						
Armada		2017	51382	51383	5	BH1
		04-15	51382	51383	5	BH1
Frontier		05-17	51382	51383	5	BH1
NV200		13-17	51382	51383	5	BH1
NV1500		12-17	51382	51383	5	BH1
NV3500		12-17	51382	51383	5	BH1
Pathfinder		04-17	51382	51383	5	BH1
Pathfinder Armada		2004	51382	51383	5	BH1
Titan		04-15	51382	51383	5	BH1
Titan XD		2016	51382	51383	5	BH1
Xterra		05-15	51382	51383	5	BH1
RAM						
1500		15-17	51457	51458	10	BH2
		13-14	-	51453	10	BH8
		11-12	51438	51439	5	BH8
2500		15-17	51457	51458	10	BH2
		13-14	-	51453	10	BH8
		11-12	51438	51439	5	BH8
3500		15-17	51457	51458	10	BH2
		13-14	-	51453	10	BH8
		11-12	51438	51439	5	BH8
4500		16-17	51457	51458	10	BH2
5500		16-17	51457	51458	10	BH2
SATURN						
Outlook		07-09	51422	51423	5	BH1
TOYOTA						
4Runner	Limited	2017	51362	51363	5	BH1
	SR5	2017	51362	51363	5	BH1
	TRD Pro	2017	51362	51363	5	BH1
		03-16	51362	51363	5	BH1
Land Cruiser		13-17	51362	51363	5	BH1
		03-11	51362	51363	5	BH1
Sequoia		03-17	51362	51363	5	BH1
Tacoma		16-17	51455	51456	5	BH4
		07-15	51362	51363	5	BH1
Tundra		15-17	51455	51456	5	BH4
		03-14	51362	51363	5	BH1
Harness Location Designators:						
BH1 = Underneath dash, left of steering column, near emergency brake pedal						
BH2 = Underneath dash, near center console						
BH3 = Underneath dash, in junction box left of steering column						
BH4 = Behind storage pocket, above ashtray						
BH5 = Underneath dash, behind center access panel on passenger side						
BH6 = Underneath dash, near brake pedal						
BH7 = Behind storage pocket in center of dash						
BH8 = Underneath dash, to right of emergency brake pedal						

Red text indicates products Continued While Supplies Last (CWSL).