



Double Lock EZr™ Application Guide

- No frame drilling required
- Some models may require lowering the exhaust
- Temporarily bend underbody flange for ease of installation

Double Lock EZr™ Installation Brackets (Rated to vehicle's max gross weight rating)

Make/Model	Style	Years From	Years To	Install Brackets#	EZr Hitch#	EZr Hitch with Install Brackets#
CHEVROLET/GMC						
Silverado/Sierra 2500/3500		2011	2017	60624	60611	60680
		2001	2010	60648	60619	60681
DODGE						
Ram 2500		2003	2010	60660	60619	60682
		2003	2010	60660	60612	60684
Ram 3500		2003	2010	60660	60619	60682
		2003	2010	60660	60612	60684
FORD						
F-250		1999	1999	60647	60619	60685
F-250 Super Duty		2011	2016	60645	60619	60683
		2011	2016	60645	60612	60688
		1999	2010	60647	60619	60685
		1999	2010	60647	60612	60689
F-350 Super Duty		2011	2016	60645	60619	60683
		2011	2016	60645	60612	60688
		1999	2010	60647	60619	60685
		1999	2010	60647	60612	60689
RAM						
2500		2011	2013	60660	60619	60682
		2011	2013	60660	60612	60684
3500		2011	2013	60660	60612	60682
		2011	2012	60660	60612	60684